

### 3SKB-SLP kit installation instructions

Items included in kit:

- (1) 12" x 7" aluminum plate
- (4) #10 x 5/8 stainless steel mounting screws
- (4) #10 rubber backed sealing washers
- (4) #10-32 nylock nuts

Tools required for installation:

- Drill motor
- 3/16" (.187") drill bit
- #2 philips screw driver
- 3/8" wrench
- Tape measure



Case with kit and required tools



Locate and align plate on case at location of your choice



Use holes on plate as drilling template



Insert a screw into each hole as you drill them to hold alignment



Push sealing washers onto the screws, note that they will be very tight because they have a rubber backing which allows them to seal the case.



Tighten the screws and nuts using the screwdriver and wrench until the domed washer becomes flat



Remove protective plastic covering from face of plate