



Cutout
template

Attach screws

Attach screw
nylock nuts

Attach screw
sealing washers

Wheel housing gasket,
PSA one side – need to
RTV the case side

3R-WK12
wheel assembly



This is the 3R-WK12 installed in a cutout corner of an SKB 3R series case. This installation is not using the correct hardware but is just to illustrate how the wheel fits into the case. Note that the housing has a long leg, and a short leg. The long leg mounts vertically up the side wall of the case, and the short leg is designed to mount horizontally along the bottom of the case. The PSA side of the gasket is designed to be stuck to the wheel housing and the installer is to apply a bead of RTV sealant on the back side of the gasket to ensure a seal to the case so as to not compromise the water tight integrity of the case.